

CE-CMHL-EX(B) Install Guide

Included Items:

- Extension Pole
- Mounting Hardware
- Instructions

Required Items:

- 7/16" Wrench
- 10mm Wrench

! Maximum Load Capacity: 60 lbs / 27.2 kgs !



CAUTION!

USE ONLY AS DESIGNED

THIS PRODUCT IS DESIGNED TO SERVE AS AN EXTENSION BETWEEN AN EXISTING HEAVY-DUTY MONITOR POLE MOUNT AND THE MONITOR OR PVM. REFER TO THE HEAVY-DUTY MONITOR MOUNT INSTALLATION GUIDE FOR DETAILS ON INSTALLING THE MONITOR POLE. NO MORE THAN ONE EXTENSION POLE SHOULD BE USED PER ASSEMBLY. IT IS INTENDED FOR USE ONLY WITH THE MAXIMUM WEIGHT INDICATED. USE WITH PRODUCTS HEAVIER THAN THE MAXIMUM WEIGHT INDICATED MAY RESULT IN INSTABILITY CAUSING POSSIBLE INJURY.

1. FEED CABLES THROUGH POLE

Feed the desired power, video, and safety cables through the wider top end of the extension pole and down through the bottom of the pole.

2. ATTACH EXTENSION TO MONITOR POLE

Slide extension pole over the end of the monitor pole and insert a bolts into each of the top two holes to join the poles together. Attach a lock washer, and locknut to each bolt, and tighten with a 10mm and 7/16" wrench.

3. ATTACH MONITOR MOUNTING PLATE

Refer to CE-CMHL heavy duty pole instructions for details on attaching monitor mounting plate.

